


ERH3 Rotary Handle

1




The manufacturer assumes no responsibility for unfavorable consequence resulting from the non-application or incorrect application of the instructions provided herein.

NOARK

ERH3 Rotary Handle


2



ERH3 Rotary Handle

MCB and Disconnect Switch


3



ERH3 Rotary Handle

MCB and Disconnect Switch


4




ERH3 Rotary Handle

Especially for Ex9IR32


5




ERH3 Rotary Handle




ERH3 Rotary Handle



ERH3 Rotary Handle



ERH3 Rotary Handle



NOARK

NOARK Electric North America

15302 E. Valley Blvd. • City of Industry, CA 91746

(626) 330-7007

www.NoarkUSA.com • NASales@Noark-Electric.com



Printed with environmentally-friendly paper.
Copyright NOARK. All rights reserved.